

Inspection Stations and Stop Switches

Top Of Car Inspection (TOCI) stations

Part Number	Description
TOCI-L	Top of car inspection box, with GFCI receptacle and light fixture/cage
TOCI-LF	Top of car inspection box, with GFCI receptacle, light fixture/cage and fire service light/buzzer indicators
TOCI-LA	Top of car inspection box, with GFCI receptacle, light fixture/cage and audible 6 - 28VDC alarm
TOCI-LFA	Top of car inspection box, with GFCI receptacle, light fixture/cage, fire service light/buzzer indicators and audible 6 - 28VDC alarm
CNTBLK-NO	Additional NO contact block
CNTBLK-NC	Additional NC contact block

TOCI stations house large, easy-to-read UP, DOWN, COMMON and STOP controls as well as a normal/inspection switch, 125VAC/25A GFCI receptacle and light fixture/cage in a bright yellow metal enclosure. They are available in four versions - with lamp fixture, lamp/fire service, lamp/alarm and lamp/fire service/alarm. NOTE: All stations come unwired; some field assembly required. Light bulb not included.



Stop switches

Part Number	Description
EN418-A	Locking stop switch

EN418-A stop switches use a push-pull action for sure, safe operation. A four-prong guard helps prevent accidental engagement of the switch. Large diagrams printed on the switch show clearly which are the RUN and STOP positions, while indicator windows show 'green for go' when the switch is in the ON position and 'red for stop' when in the STOP position.

